

How to pair SMA-RF Control Devices with an SMA-RF Receiver

These instructions will explain how to pair, or program, an SMA-RF transmitter or keypad, with a SMA-RF receiver.

1. Plug the motor and receiver into a standard 110 volt outlet.
2. Plug the modular cable of the SMA-RF receiver into either of the two modular ports located on the bottom of the drapery motor.
3. Note an access hole next to the antenna. If a green LED light is illuminated proceed to step 4. If the green light is not illuminated, using a small object press the programming button located next to the LED light. The green will illuminate and your ready for step 4.
4. Push any button on the transmitter, and the green light will turn off.
5. Your transmitter and receiver are now paired.

*To watch a video demonstration of this procedure, please view **Instructional Video #2** or <https://vimeo.com/42793541>.*