

## How to pair an RTS Control Device with an SMA-RTS receiver

These instructions will explain how to pair, or program, a Model 400 series drapery motor RTS receiver, with an RTS Telis transmitter, or DecoFlex wireless wall switch.

1. Plug the drapery motor and receiver into a standard 110 volt outlet.
2. Plug the modular cable of the SMA-RTS receiver, into either of the two modular ports, located on the bottom of the drapery motor.
3. Check to see that the LED light on the RTS receiver is on. If the LED light does not come on initially, push the master reset button, which is located next to the modular port on the receiver.
4. To pair the control device, first select the desired channel.
5. Find the Program Button on the control device. It's located on the back of the Telis transmitter, and on the front of the DecoFlex wireless wall switch.
6. Using a paper clip, press and hold the program button on the RTS transmitter, until the LED light on the receiver is off.
7. Once you release the program button, the LED will light again.
8. Once again, press and release the program button on the transmitter, and the LED light will turn off, and remain off.
9. This RTS control device is now paired.

*To watch a video demonstration of this procedure, please view [Instructional Video #4](#).*