



Program SMA with Bond Sidekick (Gen. 3) Wireless Wall Switch Model 140-S Drapery System

Step 1: Select the desired channel(s) on the Bond Sidekick switch for the SM Automatic motor. Multiple channels may be programmed to SMA at the same time.
Note: By default, the Bond switch is configured to Somfy RTS motors.

Step 2: Using the included tool, quick press and release the Menu button on the back of the Bond switch. Ensure the Stop LED light blinks for 5 seconds.

Step 3: While blinking Press the following 4 buttons:

1  3  1  ■ (STOP)

Step 4: The selected channel(s) for the SMA motor will blink to confirm change. Next follow the instructions to sync the Bond switch with the SMA 140-S drapery motor.

Pairing Bond Sidekick with SM Automatic Model 140-S Drapery Motor

Step 1: On the bottom of the Model 140-S motor, using the small tool or a paper clip, press the programming button next to the RJ-11 ports.

Step 2: The LED light will blink “red” for 10 seconds to indicate pairing mode.

Step 3: Select the desired channel and Press the “UP” arrow on the Bond switch. The LED will blink “blue” 3 times to indicate successful syncing.

Step 4: Enjoy your Bond Sidekick and SM Automatic motor.